

## Produktinformation



### Information



Tillverkare Acer

Artnr NP.CAB1A.011

## Acer - extern videoadapter - svart

### Specifikation

#### Allmänt

<b>Typ av enhet</b>	Extern videoadapter
<b>Busstyp</b>	USB-C
<b>Interfaces Details</b>	VGA USB-C

#### Diverse

<b>Färg</b>	Svart
-------------	-------

#### Kompatibilitetsinformation

#### Designat för

Acer Aspire 1 A114-61 Acer Aspire 3 A315-35, A315-35-C97V, A315-35-P2DH, A315-35-P9FS, A315-56, A315-58, A317-33, A317-33-C79R, A317-33-P3DV, A317-33-P9DS, A317-53 Acer Aspire 3 Pro Series A317-52 Acer Aspire 5 A515-44, A515-45, A517-52-31EP, A517-52-326E, A517-52G, A517-52G-74SF Acer Aspire 5 Pro Series A515-56, A517-52, A517-52G Acer Chromebook 311 C722, C733 Acer Chromebook 314 C933 Acer Chromebook 512 C851T Acer Chromebook 514 CB514-1W Acer Chromebook Enterprise Spin 513 R841LT, R841T Acer Chromebook Spin 512 R852T, R852TN, R853TA Acer Chromebook Spin 513 R841T Acer Chromebook Spin 514 CP514-1WH, CP514-1W-R57K Acer Chromebook Spin 713 CP713-2W Acer ConceptD 3 Ezel CC314-72G Acer ConceptD 3 Ezel Pro CC314-72P Acer ConceptD 3 Pro CN315-72P-54SD Acer ConceptD 7 CN715-72G-71QE, CN715-72G-7609 Acer ConceptD 7 Ezel Pro CC715-71P-79ZW Acer ConceptD 7 Pro CN715-72P-71WU,



---

CN715-72P-7672, CN715-72P-78U0 Acer Extensa 15 EX215-31, EX215-53G, EX215-54 Acer Nitro 5 AN515-45, AN515-55, AN515-55-5692, AN515-55-71JV, AN515-57, AN517-41, AN517-41-R7UX, AN517-41-R9Q2, AN517-52, AN517-54 Acer Predator Helios 300 PH315-53, PH315-54, PH317-55 Acer Predator Triton 300 PT315-53 Acer Spin 1 SP114-31 Acer Spin 3 SP313-51N-56J4, SP313-51N-71WB, SP314-54N-34UU Acer Spin 5 SP513-55N, SP513-55N-52HF Acer Spin 5 Pro Series SP513-54N Acer Spin 7 Pro Series SP714-61NA Acer Swift 1 SF114-33-C5GE, SF114-33-C6ZJ, SF114-33-P11Y, SF114-33-P17Z, SF114-34 Acer Swift 3 SF314-43, SF314-511, SF314-59-36B3, SF316-51 Acer Swift 3 Pro Series SF316-51 Acer Swift 5 Pro Series SF514-55T, SF514-55TA Acer Swift 7 Pro Series SF714-52T Acer TravelMate P2 TMP214-41, TMP214-53, TMP214-53-32LS, TMP214-53-5543, TMP215-41, TMP215-53-75AM Acer TravelMate P4 TMP414-51-54EW, TMP414-51-75QM Acer TravelMate Spin B3 TMB311RA-31, TMB311RNA-31 Acer TravelMate Spin P4 TMP414RN-51-552J, TMP414RN-51-78UQ