

Produktinformation**Information****Canon**

Tillverkare Canon
Artnr 2469A002

Canon RS-60E3 fjärrkontroll för kamera - svart**Specifikation****Allmänt**

Typ av enhet	Fjärrkontroll för kamera
Färg	Svart
Lokalisering	Engelska
Anslutningsteknologi	Kabel
Enhetsantal som stöds	1
Enheter som stöds	Digital fotokamera, fotokamera
Egenskaper	Slutarutlösninglås

Anslutningar

Anslutningstyp	1 x fjärrkontroll
-----------------------	-------------------

Diverse

Medföljande kablar	1 x fjärrkontrollkabel - integrerad - 60 cm
---------------------------	---

Kompatibilitetsinformation

Designat för	Canon EOS 100D, 1100D, 1200D, 1300D, 1500D, 2000D, 200D, 250D, 30, 300, 3000N, 3000N QD, 3000V, 300D, 300V, 300V QD, 300X, 30V, 30V Date, 33, 350D, 400D, 50, 500, 5000, 500D, 500N, 600D, 60Da, 650D, 700D, 70D, 750D, 760D, 77D, 8000D, 800D, 80D, 850D, 9000D, 90D, Digital Rebel, Digital Rebel XT, Digital Rebel XTi, ELAN 7, ELAN 7E, ELAN 7NE, Elan II, Elan IIe, IX, IX 7, Kiss X10, Kiss X10i, Kiss
---------------------	--



X5, Kiss X50, Kiss X7, Kiss X70, Kiss X7i, Kiss X80, Kiss X8i, Kiss X9, Kiss X90, Kiss X9i, M6, Rebel 2000, Rebel G, Rebel GII, Rebel SL2, Rebel SL3, Rebel T2, Rebel T3, Rebel T3i, Rebel T4i, Rebel T5, Rebel T5i, Rebel T6, Rebel T6i, Rebel T6s, Rebel T7, Rebel T7+, Rebel T7i, Rebel T8i, Rebel Ti, RP Canon PowerShot G1 X Mark III, G10, G11, G12, G16, G3 X, G5 X, SX50 HS, SX60 HS, SX70 HS